




Classic N




Classic S




Classic Tactil Malmö N



Classic Tactil Malmö S



Classic Tactil Malmö Top



Type 1
(1+1)

Type 2
(1+1R)

Type 3
(2+1R)

Type 4
(2+2R)

Type 5
(3+2R)

Type 6
(1+1R)

Type 7
(1)

Type 8