

Miscellaneous

Tempered glass

Wash as needed. The glass plate is impact resistant in the middle, but can shatter from impacts against the edge.

Solar cells

Clean with a microfibre cloth and lime-free water (below 60 degrees).

Glass assembly/rubber gasket

For glass mounting, use a rubber gasket in the upper and lower glass strips to hold the glasses. This gasket may be missing if glass has been broken and therefore a replacement supplied during reassembly. Contact us regarding the rubber gasket.

Advertising display case

Clean with a damp cloth and mild soap.

Sensors

Keep the lens clean of cobwebs, dead insects, etc.

Door hinges, lock cases and door rails

Recommended to be lubricated as needed, but at least once a year.

Door lock

To maintain the function of the locking cylinder, it is recommended to use a suitable lock spray after every 5000 openings, but at least once every six months. Never use graphite, oil or grease in the cylinder.

Door pumps

When setting the closing speed, closing delay and constant holding, remove the cover plate over the door cylinder, after which remove the 2-component DORMA packing compound with a knife. The valve screws can then be used to set the mentioned functions. Refer to the manufacturer for more information.

Screws/bolts

All screws and bolts are delivered in stainless A2 quality. Screws/bolts should be retightened 3 months after delivery.